

Energy Development Category Type (EDCT)	Facility Sub-Type (Petrinex)
320 & 420 = Single Well Oil Battery	311 = Crude Oil Single Well Battery
030 & 321 & 421 = Multiwell Oil Battery	321 = Crude Oil Multiwell Group Battery 322 = Crude Oil Multiwell Proration Battery
330 & 430 = Single Well Bitumen Battery	331 = Crude Bitumen Single Well Battery
031 & 331 & 431 = Multiwell Bitumen Battery	341 = Crude Bitumen Multiwell Group Battery 342 = Crude Bitumen Multiwell Proration Battery
310 & 410 = Single Well Gas Battery	351 = Gas Single Well Battery
020 & 311 & 411 = Multiwell Gas Battery	361 = Gas Multiwell Group Battery 362 = Gas Multiwell Effluent Measurement Battery 363 = Gas Multiwell Proration SE Alberta Battery 364 = Gas Multiwell Proration Outside SE Alberta Battery
010 = Gas Processing Plant	401 = Gas Plant Sweet
300 & 400 = Gas Processing Plant	402 = Gas Plant Acid Gas Flaring < 1T/D Sulphur 403 = Gas Plant Acid Gas Flaring > 1T/D Sulphur 404 = Gas Plant Acid Gas Injection
301 & 401 = Gas Fractionation Plant	407 = Gas Plant Fractionation
600 = Sulphur Recovery Gas Plant	405 = Gas Plant Sulphur Recovery
200 & 302 = Straddle Plant	406 = Gas Plant Mainline Straddle
011 = Gas Fractionation Plant	407 = Gas Plant Fractionation
090 = Injection/Disposal Facility (Water)	503 = Disposal
091 = Injection/Disposal Facility (EOR)	507 = Disposal (Approved as part of a waste plant)
040 & 340 & 440 = Compressor Station	601 = Compressor Station (non-reporting)
080 = Custom Treating Facility	611 = Custom Treating Facility 612 = Custom Treating Facility (Approved as part of a waste plant)
070 & 350 & 450 = Oil Satellite 071 & 351 & 451 = Bitumen Satellite	None (non-reporting)

Energy Development Category Type (EDCT) codes are assigned at the licence level. If there are two or more facilities on the same licence, the EDCT code of the highest priority facility will be assigned to all of the facilities on that licence.